

# Installation instructions for the intake manifold module without sensor

**B34.960** | Audi

Elring supplies the intake manifold module for the Audi 2.5-litre V6 engines CLXB, CPAA, and CVBA without the sensor or potentiometer for the intake manifold flap.


The existing sensor can still be used and must therefore be transferred from the old component to the new intake manifold module. The sensor is mounted on the upper part of the module. It is directly attached to the intake manifold and secured with screws.



## Instructions

1. Ensure the vehicle is switched off and the battery disconnected to prevent electrical hazards.
2. Loosen the two screws securing the sensor to the old intake manifold.
3. Carefully remove the sensor.
4. Install the new intake manifold module and tighten the screws in the specified sequence to a torque of 8 Nm/5.90 ft-lb.
5. Attach the sensor to the new intake manifold and fasten the two screws.

**Note:** Make sure that the sensor is securely mounted to ensure proper operation. After installation, perform a function check.



TecDoc

**ElringKlinger AG | Aftermarket Division**

Max-Eyth-Straße 2 | 72581 Dettingen/Erms | Germany

Phone +49 7123 724-799

service@elring.com | www.elring.com

SI 03/2025



**Das Original**